

DESIGNER | RECESSED WALL LIGHT | HS

Replacement Parts

ITEM	DESCRIPTION	PART #
1	Install Sleeve	†
2	Install Brackets	†
3	Screw, #6-32 x ¼"	250010210000
1-3	Mounting Kit, HS	MK-HS
4	Screw #6-32 x ¾"	250028400000
5	Housing	†
6	Socket, 10' (3 m)	†
7	LED Board	See LED Chart
8	Reflector	See LED Chart
9	Screw, #4-40 x ¾"	See LED Chart
7-9	LED Board Assembly	See LED Chart
10	Lens	†
11	Gasket, Lens	†
10-11	Lens Assembly Kit	HS-LA
12	Gasket, Faceplate	†
13	Faceplate	†
14	O-Ring	†
15	Screw, #6-32 x ½"	†
12-15	Faceplate LS Assembly	HS-FP-LS-XX*
NS	Hex Key, 7/64"	250036520100

LED Chart

ITEM	DESCRIPTION	PART #
7-9	2 LED Warm (2700K) Board Assembly	2LED-W-KIT-R
7-9	2 LED Cool (3900K) Board Assembly	2LED-C-KIT-R
7-9	ZDC Board Assembly	ZDC-KIT-R-3

NS = Not shown

*XX = Finish code

† This part is not serviceable. Contact Customer Support or a local distributor to order a new product.

