

DESIGNER | ACCENT LIGHT | XA

Replacement Parts

ITEM	DESCRIPTION	CATALOG #
1	Shroud with Lens	LCXA70XX*
2	Screws, Optics	KITOPXA70H1YY*
3	LED Board	See LED Chart
4	O-Ring	250010280034
5	Driver	†
6	Body	†
7	Set Screw, 1/4"-20 x 3/8", 1/8" Allen key, Qty: 12	250032740000SP
8	Assembly, Knuckle	KAM050EXAXX*
9	Long Slot Spike (LSS)	250015840000
10	Mini J-Box	MJB050XX*

XX* = Finish code

YY* = Beam angle (SP, FL, WF)

†This part is not serviceable. Contact Customer Support or a local distributor to order a complete product.

LED Replacement

DESCRIPTION	CATALOG #
LED Board, H1, Warm 2,700K	KITH1W*
LED Board, H1, Soft 3,000K	KITH1S*
LED Board, Zone/Dim, H1, Warm 2,700K	KITZDH1W*
LED Board, Zone/Dim, H1, Soft 3,000K	KITZDH1S*
LED Board, ZDC, 6 LED	KITZDC6*

* = Zoning, Zone/Dim, and ZDC boards are not interchangeable on the same fixture.

