## STANDARD | WALL WASH | WS

## Replacement Parts

ITEM	DESCRIPTION	PART#
1	Screw, #8-32 x 7/16"	250022400000
2	Lens, Frosted	t
3	Shroud	t
2-3	Lens Cap, Frosted	WS-LC-XX*
4	O-Ring for Shroud	250010280038
5	Lamp, G4	See Lamp Chart
6	Socket, 10' (3 m)	754601
7	Reflector	†
8	Body	†
9	Knuckle Base	See Knuckle Base Chart
10	Screw, #10-24 x 3/8"	250013940000
11	O-Ring for Knuckle	250010280002
12	Knuckle Fitting	†
13	Screw, ¼"-20 x ¾"	250010290000
12-13	Knuckle Fitting Subassembly	KFM-050-XX*
14	Critter Plug	250031010000SP
15	Lock Ring	250030410000SP
16	Super Slot Spike	753900
NS	Hex Key, 9/64"	t

### Knuckle Base

PART#
252201
252206
252207
252209
252214
252215
252221




<sup>\*</sup> XX = Finish code

<sup>†</sup>This part is not serviceable. Contact Customer Support or a local distributor to order a new product.







# LAMPS | G4 LAMPS

# G4 LED Lamp Chart

LUMENS / VA	ССТ	PART#
76 lm / 1.1 VA	2700K	G4-LED-10-W
123 lm / 1.7 VA	2700K	G4-LED-20-W
170 lm / 2.6 VA	2700K	G4-LED-35-W
76 lm / 1.1 VA	3000K	G4-LED-10-S
123 lm / 1.7 VA	3000K	G4-LED-20-S
170 lm / 2.6 VA	3000K	G4-LED-35-S

