

STANDARD | WALL WASH | WS


Replacement Parts

ITEM	DESCRIPTION	PART #
1	Screw, #8-32 x 7/16"	250022400000
2	Lens, Frosted	†
3	Shroud	†
2-3	Lens Cap, Frosted	WS-LC-XX*
4	O-Ring for Shroud	250010280038
5	Lamp, G4	See Lamp Chart
6	Socket, 10' (3 m)	754601
7	Reflector	†
8	Body	†
9	Knuckle Base	See Knuckle Base Chart
10	Screw, #10-24 x 3/8"	250013940000
11	O-Ring for Knuckle	250010280002
12	Knuckle Fitting	†
13	Screw, 1/4"-20 x 3/4"	250010290000
12-13	Knuckle Fitting Subassembly	KFM-050-XX*
14	Critter Plug	250031010000SP
15	Lock Ring	250030410000SP
16	Super Slot Spike	753900
NS	Hex Key, 9/64"	†

NS = Not shown

*XX = Finish code

†This part is not serviceable. Contact Customer Support or a local distributor to order a new product.



Knuckle Base

DESCRIPTION	PART #
Knuckle Base, Bronze Metallic	252201
Knuckle Base, Desert Granite	252206
Knuckle Base, Sedona Brown	252207
Knuckle Base, Weathered Iron	252209
Knuckle Base, Black	252214
Knuckle Base, Flat White	252215
Knuckle Base, Silver	252221

LAMPS | G4 LAMPS

G4 LED Lamp Chart

LUMENS / VA	CCT	PART #
1.0 VA / 75 lm	2700K	G4-E-1-W
1.3 VA / 120 lm	2700K	G4-E-2-W
1.7 VA / 170 lm	2700K	G4-E-3-W
1.0 VA / 80 lm	3000K	G4-E-1-S
1.3 VA / 130 lm	3000K	G4-E-2-S
1.7 VA / 190 lm	3000K	G4-E-3-S

